


Instruction Manual DISSOLVED OXYGEN METER LAQUA-DO210 LAQUA-DO220



Portable pH·Water Quality Meter

Preface

This manual describes the operation of the following instrument.

Brand:	LAQUA
Series name:	LAQUA 200 Series Handheld Water Quality Meter
Model:	LAQUA-DO210, LAQUA-DO220
Model description:	Dissolved Oxygen Meter

Be sure to read this manual before using the product to ensure proper and safe operation of the product. Also, safely store the manual so it is readily available whenever necessary. Product specifications and appearance, as well as the contents of this manual are subject to change without notice.

Warranty and responsibility

HORIBA Advanced Techno Co., Ltd. warrants that the product shall be free from defects in material and workmanship and agrees to repair or replace free of charge, at option of HORIBA Advanced Techno Co., Ltd., any malfunctioned or damaged product attributable to responsibility of HORIBA Advanced Techno Co., Ltd. for a period of Three (3) years from the delivery unless otherwise agreed in a written statement. In any one of the following cases, none of the warranties set forth herein shall be extended:

- Any malfunction or damage attributable to improper operation
- Any malfunction attributable to repair or modification by any person not authorized by HORIBA Advanced Techno Co., Ltd.
- Any malfunction or damage attributable to the use in an environment not specified in this
 manual
- Any malfunction or damage attributable to violation of the instructions in this manual or operations in the manner not specified in this manual
- Any malfunction or damage attributable to any cause or causes beyond the reasonable control of HORIBA Advanced Techno Co., Ltd. such as natural disasters
- Any deterioration in appearance attributable to corrosion, rust, and so on
- · Replacement of consumables

HORIBA Advanced Techno Co., Ltd. SHALL NOT BE LIABLE FOR ANY DAMAGES RESULTING FROM ANY MALFUNCTIONS OF THE PRODUCT, ANY ERASURE OF DATA, OR ANY OTHER USES OF THE PRODUCT.

Trademarks

• Microsoft, Windows, Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.

Other company names and brand names are either registered trademarks or trademarks of the respective companies. (R), (TM) symbols may be omitted in this manual.

CODE:GZ0000553858A October, 2019 © 2019 HORIBA Advanced Techno, Co., Ltd.

Regulations

- EU regulations
- Conformable standards


This equipment conforms to the following standards:

	E	EMC: RoHS:	EN61326-1 Class B, Basic electromagnetic environment EN50581 9. Monitoring and control instruments
-	Warning:	industrial environn cause the incorrec	t intended for use in industrial environments. In an nent, electromagnetic environmental effects may ct performance of the product in which case the ired to take adequate measures.

• Information on disposal of electrical and electronic equipment and disposal of batteries and accumulators

The crossed out wheeled bin symbol with underbar shown on the product or accompanying documents indicates the product requires appropriate treatment, collection and recycle for waste electrical and electronic equipment (WEEE) under the Directive 2012/19/EU, and/or waste batteries and accumulators under the Directive 2006/66/EC in the European Union. The symbol might be put with one of the chemical symbols below. In this case, it satisfies the requirements of the Directive 2006/66/EC for the object chemical. This product should not be disposed of unsorted household waste. Your correct disposal of WEEE, waste batteries and accumulators will contribute to reducing wasteful consumption of natural resources, and protecting human health and the environment from potential negative effects caused by hazardous substance in products.

Contact your supplier for information on applicable disposal methods.



Authorised representative in EU

HORIBA Europe GmbH Hans-Mess-Str.6, D-61440 Oberursel, Germany

• FCC rules

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party for FCC matter

HORIBA Instruments Incorporated Head Office 9755 Research Drive Irvine, California 92618 USA +1 949 250 4811

Note

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Korea certification

B급 기기 (가정용 방송통신기자재)

이 기기는 가정용(B 급) 전자파적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

Taiwan battery recycling marks



Regulations

• China regulation 标记的意义 Meaning of Marking

> 本标记适用在中华人民共和国销售电器电子产品,标记中央的数字 表示环境保护使用期限的年数。(不是表示产品质量保证期间。) 只要遵守这个产品有关的安全和使用注意事项,从制造日开始算起 在这个年限内,不会给环境污染、人体和财产带来严重的影响。请 不要随意废弃本电器电子产品。



This marking is applied to electric and electronic products sold in the People's Republic of China. The figure at the center of the marking indicates the environmental protection use period in years. (It does not indicate a product guarantee period.) It guarantees that the product will not cause environment pollution nor serious influence on human body and property within the period of the indicated years which is counted from the date of manufacture as far as the safety and usage precautions for the product are observed. Do not throw away this product without any good reason. 产品中有害物质的名称及含量

	有害物质 Hazardous substances					
部件名称 Unit name	铅 Lead (Pb)	汞 Mer- cury (Hg)	镉 Cad- mium (Cd)	六价铬 Hexa- valent chromium (Cr (VI))	多溴联苯 Poly bromobi- phenyl (PBB)	多溴二苯醚 Poly bromo- diphenyl ether (PBDE)
本体 Main unit	×	0	0	0	0	0
电池 Battery	×	0	0	0	0	0
AC 适配器 AC adopter ^{*1,*2}	×	0	0	0	0	0
电缆 Cable ^{*2}	×	0	0	0	0	0
支架 Stand ^{*2}	0	0	0	0	0	0
打印机 Printer ^{*2}	×	0	0	0	0	0
电极 Electrode ^{*2}	×	0	×	0	0	0

Name and amount of hazardous substance used in a product

本表格依据 SJ/T 11364 的规定编制。

This form is prepared in accordance with SJ/T 11364.

〇:表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要

求以下。

Denotes that the amount of the hazardous substance contained in all of the homogeneous materials used in the component is below the limit on the acceptable amount stipulated in the GB/T 26572.

X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的 限量要求。

Denotes that the amount of the hazardous substance contained in any of the homogeneous materials used in the component is above the limit on the acceptable amount stipulated in the GB/T 26572.

*1:本部件的环保使用期限为 10 年。 The environmental protection use period of this product is 10 years.
*2:选配件 Optional products

• For Your Safety

• Hazard classification and warning symbols

Warning messages are described in the following manner. Read the messages and follow the instructions carefully.

Hazard classification

▲DANGER	This indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. This is to be limited to the most extreme situations.
▲ WARNING	This indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	This indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
Warning symbols	



Description of what should be done, or what should be followed.



Description of what should never be done, or what is prohibited.

Safety precautions

This section provides precautions for using the product safely and correctly and to prevent injury and damage. The terms of DANGER, WARNING, and CAUTION indicate the degree of immanency and hazardous situation. Read the precautions carefully as it contains important safety messages.

Instrument and electrode

\land WARNING

Do not disassemble or modify the instrument. Otherwise, it may heat up or be ignited resulting in a fire or an accident.

Harmful chemicals

Some electrodes are used with hazardous standard solutions. Handle them with care. The internal solution of DO electrode is highly concentrated potassium hydroxide (KOH). If the internal solution comes in contact with the skin, wash it off immediately. If it gets into the eyes, flush with plenty of water and then consult a doctor.



Do not use the phono jack under wet or humid conditions. Otherwise, it may cause a fire, electric shock, or breakage.

Battery

	<u> </u>
0	Keep batteries out of reach of children. If someone accidentally swallows a battery, consult a doctor immediately.
0	If alkaline fluid from a battery gets into the eyes, do not rub the eyes, rinse with clean water immediately and then consult a doctor. Contact with alkaline fluid could cause blindness.
\bigcirc	Do not put batteries in a fire, expose to heat, disassemble or remodel. Doing so can case fluid leakage, overheating or explosion.

Product Handling Information

Operational precautions (instrument)

- Only use the product including accessories for their intended purpose.
- Do not drop or physically impact the instrument.
- The instrument is made of solvent-resistant materials but that does not mean it is resistant to all chemicals. Do not expose the instrument in strong acid or alkali solution, or wipe with such solution.
- If the instrument is dropped into water or gets wet, wipe it using soft cloth. Do not heat to dry it.
- The instrument has a dust-proof and waterproof structure i.e., the instrument does not malfunction even when immersed in water of 1 m depth for 30 minutes. This does guarantee non-destructive, trouble-free, dust-proof, and waterproof performance in all situations.
- When replacing the batteries or when a serial cable connected, the instrument does not have the dust-proof and waterproof performance. The dust-proof and waterproof performance is maintained only when the covers are attached correctly.
- After replacing the batteries or removing the serial cable connected, make sure that the waterproof gasket attached to the cover is not deformed or discolored, or has foreign matter adhering to it. If the waterproof gasket is deformed, discolored or has foreign matter adhering to it, dust could get inside, water leaks could occur that could lead to instrument malfunction.
- To disconnect an electrode or serial cable, hold the connector and pull it off. If you pull at the cable, it may cause breakage.
- The phono jack communication between the instrument and a personal computer (referred to as PC in the rest of this document) may fail because of environmental conditions, such as electromagnetic noise.
- Do not replace the batteries in a dusty place or with wet hands. Dust or moisture could get inside the instrument, possibly causing instrument malfunction.
- Do not use an object with a sharp end to press the keys.
- If the power supply is interrupted while measurement data is being saved in the instrument, the data could be corrupted.
- A Ni-MH rechargeable battery can be used in this instrument.

Operational precautions (battery)

- Do not short circuit a battery.
- Position the + and side of the battery correctly.
- When the battery has depleted or the instrument will not be used for a long time, remove the batteries.
- Of the specified battery types, make sure to use two batteries of the same type.
- Do not use a new battery together with a used battery.
- Do not use a fully charged nickel-metal hydride battery together with a partially charged battery.
- Do not attempt to charge a non-rechargeable battery.

• Environmental conditions for use and storage

- Temperature: 0 °C to 45 °C
- Humidity: under 80% relative humidity and free from condensation

Avoid the following conditions:

- Strong vibration
- Direct sunlight
- Corrosive gas environment
- · Locations close to an air-conditioner
- Direct wind

Transportation

When transporting the instrument, repackage it in the original package box. Otherwise, it may cause instrument damage.

Disposal

- Standard solution used for the calibration must be under neutralized before the disposal.
- When disposing of the product, follow the related laws and regulations of your country for disposal of the product.


Contents

■ Product Overview1
Package Content 1
Key Features 2
Product components 3
■ Basic operations7
 Mode and measurement9
Calibration 11
DO Calibration 11
Temperature Calibration 17
■ Data 19
Data capture and storage 19
• Data transfer 20
_
■ Setup 21
 Setup
•
• P1 DO setup 21
• P1 DO setup 21 • wP2 Data setup 25
 P1 DO setup

Product Overview

This section describes the package content, key features and product components of LAQUA DO200 handheld meters.

• Package Content



After opening the carry case, remove the meter and check for damage on the instrument and confirm that the standard accessories all exist. If damage or defects are found on the product, contact your dealer.


LAQUA DO200 Series Handheld meter and meter kit include the following items:

S.NO.	Name
1	Instrument
2	Instruction manual
3	2 AA batteries
4	Electrode

• Key Features


- IP67 water ingress, dust-proof, shock-resistant, anti-slip meter housing.
- Large monochrome LCD (50 x 50 mm) with white LED back lighting.
- Built-in electrode holder (up to 2 electrodes).
- Foldable meter stand.
- Simple user interface and single parameter display.
- 500 (for DO210) / 1000 (for DO220) data memory.
- Automatic Temperature Compensation (ATC) with temperature calibration.
- Adjustable auto shut-off time (1 to 30 minutes).
- Auto-hold / Auto stable / Real-time measurement modes with stability indicators.
- Powered by 2 x AA batteries.
- Real-time clock (only for DO220).
- PC (standard USB) / Printer (25 pin serial) connection via 2.5 mm diameter phono jack.

• Product components



No	Name	Function
1	Monochrome LCD	Displays the measured value
2	Operation keys	Used for instrument operation
3	Electrode connector	Connect to the BNC connector of the electrode
4	Temperature connector (T)	Connect to the temperature sensor of the electrode
5	Battery cover	Open/close to insert/remove batteries
6	Electrode holder	Hold the electrode to carry with the instrument
7	Meter stand	Open stand to place the meter at an inclined position on a flat surface
8	Serial connector	Connects to the PC or printer with the appropriate cable

• Display



No	Name	Function
1	Status Icon	Displays the current operation mode (Setup, Calibration, Measurement and Data mode)
2	Parameters	Displays the measured parameters like DO
3	\odot	Stability indicator shows value is stable for the documentation in auto-stable and auto-hold modes
4	HOLD	Appears when the measured value display is stable and fixed in auto-hold mode
5	Temperature display area	Displays the measured temperature
6	Measured value, set item display area	Displays the measured value and the set value
7	T	Indicates electrode sensitivity level
8	ERR	Indicate error situations
9	.	Indicates data being transfered to the printer or computer
10	ppmmV% m S/cmpH pptkMΩ·cmg/L	Displays the unit for the measurement parameter
11	(III)	Displays the battery level


• Battery level display

111	100% battery life
œ	50% battery life
	20% battery life
C	Batteries are weak and need replacement. Refer "BATT LOW" on page 39 to solve this

• Electrode sensitivity level

P	Electrode sensitivity 95% (excellent)
	Electrode sensitivity between 85% to 95% (very good)
[]	Electrode sensitivity between 80% to 85% (good). Refer "SLPE ERR" on page 39 to solve this

• Keypad operation



Keypad operation	Name	Function
Р	CAL key	Switches from the measurement mode to the calibration mode. Starts calibration in the calibration mode.
\sim	MEAS key	Switches from the operation mode to the measurement mode. Releases the fixed measurement value mode in the auto hold mode and begins a new measurement.
F	DATA key	Switches from the measurement mode to the data mode.
()	MODE key	In the measurement mode, changes measurement parameters.
Z,	SET key	Switches from the measurement mode to the setup mode.
•	ENTER key	Determines the selection or setup. Saves data in the measurement mode and calibration mode.
	UP key	In the setup mode, navigates between the setup. Selects preferred option in some setup screens.
▼	DOWN key	Increases or decreases selected digit when entering numbers.
ባ	POWER key	Powers ON/OFF the instrument.

Basic operations

This section describes function and basic operation method of each part of LAQUA DO200 handheld meter.

• Turning on the instrument

Inserting the batteries

This instrument is operated by batteries. You can use AA alkaline batteries or AA Ni- MH chargeable batteries. Perform the following procedure to insert batteries in the instrument.

- Unscrew the battery cover on the back of the instrument counter-clock wise to unlock the battery cover.
- 2. Remove the battery cover and set the batteries inside.
- 3. Replace battery cover.
- 4. Screw the battery cover on the back of the instrument clockwise to lock the battery cover.




- Do not replace the batteries in a dusty place or with wet hands. Dust or moisture could get inside the instrument and possibly cause an instrument malfunction.
- Do not short-circuit a battery.
- Note polarity as shown in the battery compartment.
- When the battery has depleted or the instrument will not be used for a long time, remove the batteries.
- Of the specified battery types, make sure to use two batteries of the same type.
- Do not use a new battery together with an used battery.

• Connecting an electrode

To perform calibration / measurement, it is necessary to use the appropriate electrode for measurement parameter. Use the following procedure to correctly connect the electrode to the instrument.

- 1. Insert the electrode connector by fitting its groove with the connector pin of the instrument.
- 2. Turn the electrode connector clockwise by following the grooves.
- 3. Slide the connector cover on the connector.
- 4. When using a combination electrode equipped with a temperature sensor, insert the temperature jack (T) to the ATC socket on the meter.



• Mode and measurement

• Changing the operation mode


You can change the operation mode to four available modes depending on the purpose of use. The status icon indicates the current mode.

Status icons — SET CAL MEAS DATA

lcon	Name	Function
SET	Setup mode	Perform various setup functions.
CAL	Calibration mode	Performs calibration.
MEAS	Measurement mode	Performs measurement.
DATA	Data mode	Performs data setup. Displays the saved data.


You can change the operation mode using the corresponding key:

- Measurement mode: Press the 🕎 key to change to the measurement mode.
- Calibration mode: In the measurement mode, press the 🖸 key to change to the calibration mode.
- Data mode: In the measurement mode, press the 🗦 key to change to the data mode.
- \cdot Setup mode: In the measurement mode, press the \bigotimes key to change to the setup mode.



• Changing the measurement parameter

This instrument measures multiple parameters. For measurement, an electrode corresponding to the measurement parameter is required. In the measurement mode, the measurement parameter can be changed by pressing the () key.



• Calibration

This section describes the basic calibration method using LAQUA DO200 handheld meters and DO electrode.

DO Calibration

Calibration is necessary for accurate dissolved oxygen measurement. Two calibration modes are available in DO meter for calibration,

- Saturated oxygen concentration mode (%)
- Dissolved oxygen measurement mode (mg/L)

To perform various DO calibrations, follow the procedures detailed below:



Set the air pressure value (default setup is 101.3 kPa) before calibration for accurate measurement.

• Calibration in saturated oxygen concentration mode (%)

Prerequisites

- Clean the membrane at the tip of the DO electrode with DI (deionized) water and wipe it with tissue paper.
- Switch on the DO meter and plug in the DO electrode.
- Press the **(**) key to keep the DO meter in saturated oxygen concentration mode (%) mode.

Note

- Calibration performed in clean air is referred as air calibration.
- Perform the air calibration in clean air at a location not subjected to dramatic temperature change, rain or direct wind.
- Do not hold the tip of DO electrode with hand during calibration, as the electrode may be affected by temperature causing instability in calibration value.


Тір _____

• Air calibration

- 1. Hold the DO electrode still in clean air.
- 2. Press the P key. Meter starts checking various calibration values with a blinking 🕑 on screen.
- 3. Wait for the 😳 to stabilize (stable calibration reading).
- 4. Press the **ENT** key to confirm and save calibration data.
- 5. Meter displays **DONE** indicating end of the air calibration procedure.




The electrode responds slightly differently to atmospheric air as compared to water. As such, 100% calibration in air will be shown as approximately 105%. Don't be alarmed by this.The reading in water will be accurate.



If you want to know previous calibrated values, press the 🕞 key when you are in the CAL mode.The display scrolls through the calibrated values and indicates slope and offset values.

Zero calibration

- 1. Dip the DO electrode in the zero standard solution.
- 2. Press the D key. Meter starts checking various calibration values with a blinking 🕲 on screen.
- 3. Wait for the 😳 to stabilize (stable calibration reading).
- 4. Press the \square key again to move to Zero Calibration mode.
- 5. Press the **ENT** key to confirm and save calibration data.
- 6. Meter displays **DONE** indicating end of the zero calibration procedure.



- Calibration performed with zero standard solution is referred as zero calibration.
- Prepare zero standard solution by adding 50 g of sodium sulfite (Na₂SO₃) to 1000 mL deionized water and stirring the mixture to completely dissolve the Na₂SO₃.

DO calibration

• Calibration in dissolved oxygen measurement mode (mg/L)

Prerequisites

- Clean the membrane at the tip of the DO electrode with DI (deionized) water and wipe it with tissue paper.
- Prepare required standard solutions (high-concentration and low-concentration solutions).
- Switch on the DO meter and plug in the DO electrode.
- Dip the DO electrode at least 6 cm in the standard solution.
- Press the () key to keep the DO meter in dissolved oxygen measurement mode (mg/L) mode.




- Calibrate in the dissolved oxygen measurement mode in the order from high-concentration solution to a low-concentration solution.
- User can adjust the measured dissolved oxygen reading by calibration and the adjusted value is applied as an off set to the actual measurement.
- Prepare high-concentration solution by aerating a sample of fresh water for about 2 hours.

Tip _____

To abort an ongoing calibration process at any point of time, press the K key.


• 1st point calibration

- 1. After placing the DO electrode in the high concentration solution, press the 🔁 key. Meter starts checking various calibration values with a blinking 🙂 on screen.
- 2. Wait for the 😳 to stabilize (stable calibration reading).
- 3. Use the $\blacktriangle \nabla$ keys to adjust the DO reading.
- 4. Press the ENT
 key to confirm and save calibration data.
- 5. Meter displays CAL DONE indicating end of the calibration procedure.



• 2nd point calibration

- After placing the DO electrode in the low concentration solution (zero standard solution), press the → key. Meter starts checking various calibration values with a blinking on screen.
- 2. Wait for the 😳 to stabilize (stable calibration reading).
- 3. Press the \square key again to move to Zero Calibration Mode.
- 4. Use the $\blacktriangle \nabla$ keys to adjust the DO reading.
- 5. Press the **ENT** key to confirm and save calibration data.
- 6. Meter displays **CAL DONE** indicating end of the calibration procedure.



• Temperature Calibration

Temperature calibration is required to accurately match the DO electrode to the meter. Check the temperature reading and if its acceptable, no temperature calibration is required. If you need to calibrate, please follow the procedure detailed below:

Prerequisites

- · Clean the DO electrode with DI (deionized) water and wipe it with tissue paper.
- Switch on the DO meter and plug in the DO electrode and temperature sensor.
- Dip the DO electrode in the standard solution till its temperature sensor is immersed.
- Wait for 5 minutes to ensure temperature stability.




- Meter displays **MTC** if the temperature sensor is not plugged in and displays **ATC** if the temperature sensor is plugged in.
- Temperature calibration must be performed using a known temperature solution or against a calibrated thermometer.

Tip

To abort an ongoing calibration process at any point of time, press the ∞ key.

Calibration

- 1. After placing the DO electrode in the standard solution, press the \square key.
- 2. Press the **()** key to switch to temperature calibration mode. Meter displays measured temperature value.
- 3. Use the $\blacktriangle \nabla$ keys to adjust the temperature to the required value.
- 4. Press the **ENT** key to save calibration data.
- 5. Meter displays **DONE** indicating end of the temperature calibration procedure.



Data


This section describes the basic method of data transferring using LAQUA DO200 handheld meters.

• Data capture and storage

In LAQUA DO200 handheld meters, data measured by the instrument can be stored in the internal memory.

To save the measured data:

- Press the ENT
 key to save the displayed data.
- Meter displays the saved data for 2 seconds and then the display returns to the previous screen automatically.



Note

- If the data storage limit reaches 500 in DO210 model or 1000 in DO220 model, memory full error occurs and **MEM FULL** is displayed.
- In such case, print the data or transfer necessary data to a PC (only for DO220) and delete the data from the internal memory of the instrument.

Viewing stored data

- To view stored data, press 📑 key .
- Use ▲ ▼ keys to review different stored records.
- Press
 key to return to measurement mode.



• Data transfer

• Transfer data to PC

Connect the instrument to a PC using the phono plug to USB cable to transfer saved data to the PC (for LAQUA DO220 only). Connect the phono jack at the instrument side to the communication port on the PC.

• Print data

To print a desired data set:

1. When the instrument is in the measurement mode, press \blacksquare key.

- 2. Use \blacktriangle \bigtriangledown keys to view desired stored data.
- 3. Press key to print that individual data.

• Printer format- measurement

Meter Model	: HORIBA DO220
Serial Number	: 123456789
SW Revision	: 1.00
Date	: 20 Aug 2018
Time	: 10:10:28
Mode	: DO
DO	: 100.0 %
Temperature	: 25.0 C (MAN)
Electrode Status	: Excellent
User Name	:
Signature	:

Тір _____

To print entire stored data log, refer "P2.2 Print data setup" on page 27.

Setup

This section describes all the setup functions available in LAQUA DO200 handheld meters.

• P1 DO setup

Using P1 DO setup function of the meter, you can:

- Set salinity value
- Set barometric pressure
- Erase calibration data

To set the DO functions using LAQUA DO200 handheld meter, follow the procedure detailed below:

Prerequisites

Switch on the DO meter.

Note


- Default salinity value is **0.0 ppt**. You can set a value in between 0.0 to 40.0 ppt.
- Default barometric pressure is **101.3 kPa**. You can set a value in between 10.0 to 200.0 kPa.
- Erasing previous calibration data is recommended for accurate calibration. Default setup is **NO** but to erase the calibration data, you need to change the setup to **YES**.

_ Tip _____

To return to the measurement mode, press the ∞ key.


• P1.1 Salinity value setup

- 1. Press the 🎇 key, **P1 DO** screen appears.
- 2. Press the ENT
 key, P1.1 SAL screen appears.
- 3. Press the ENT
 key, by default SAL 0.0 ppt appears.
- 4. Use the \blacktriangle \blacksquare keys to adjust the salinity value in between 0.0 to 40.0 ppt.
- 5. Press the ENT key, P1.1 SAL screen appears. This indicates completion of salinity value setup.




• P1.2 Barometric pressure setup

- 1. Press the 🍣 key, **P1 DO** screen appears.
- 2. Press the ENT
 key, P1.1 SAL screen appears.
- 3. Press the key, **P1.2 PRES** screen appears.
- 4. Press the ENT
 key, by default PRES 101.3 appears.
- 5. Use the \blacktriangle V keys to adjust the barometric pressure in between 10.0 to 200.0 kPa.
- 6. Press the ENT key, P1.2 PRES screen appears. This indicates completion of barometric pressure setup.



• P1.3 Erase calibration data

- 1. Press the 🍣 key, **P1 DO** screen appears.
- 2. Press the ENT
 key, P1.1 SAL screen appears.
- 3. Press the **k**ey, **P1.2 PRESS** screen appears.
- 4. Press the **k**ey, **P1.3 C.CLr** appears.
- 5. Press the ENT key, C.CLr NO screen appears with NO as default setup.
- 6. Use the \blacktriangle vers to change the setup to YES. This erases the calibration data.



• wP2 Data setup

Using P2 Data setup function of the meter, you can:

Set data log interval

Print data log

• Erase data log

To set the data functions using LAQUA DO200 handheld meter, follow the procedure detailed below:

Prerequisites

Switch on the DO meter.

Note


Data log interval can be set from 2 to 999 seconds.

- Tip _

To return to the measurement mode, press the ∞ key.


• P2.1 Data log interval setup

- 1. Press the 🍣 key, **P1 DO** screen appears.
- 2. Press the key, P2 DATA screen appears.
- 4. Press the ENT level, previously set log interval appears.
- 5. Use the \blacktriangle ∇ keys to set the data log interval.
- 6. Press the ENT key, P2.1 LOG screen appears. This indicates completion of data log interval setup.




• P2.2 Print data setup

- 1. Press the 🍣 key, **P1 DO** screen appears.
- 2. Press the **k**ey, **P2 DATA** screen appears.
- 3. Press the ENT
 key, P2.1 LOG screen appears.
- 4. Press the key, **P2.2 PrNT** screen appears.
- 5. Press the ENT
 key, default setup is NO.
- 6. Use the \blacktriangle \bigtriangledown keys to change the setup to **YES**.
- 7. Press the ENT key, P2.2 PrNT screen appears. This indicates completion of the print data.



- P2.2 Erase data
 - 1. Press the 炎 key, **P1 DO** screen appears.
 - 2. Press **k**ey, **P2 DATA** screen appears.
 - 3. Press the ENT level, P2.1 LOG screen appears.
 - 4. Press the key, **P2.2 PRNT** screen appears.
 - 5. Press the **k**ey, **P2.3 D.CLR** screen appears.
 - 6. Press the ENT
 key, default setup is NO.
 - 7. Use the \blacktriangle \bigtriangledown keys set it to **YES** to erase all the data.
 - 8. Press the ENT key, P2.3 D.CLR screen appears. This indicates completion of the erase data.



• P3 General setup

Using P3 General setup function of the meter, you can:

- Select stability mode of the meter
- Set auto shut-off time
- Select temperature measurement
- Reset the meter

To set the general functions using LAQUA DO200 handheld meter, follow the procedure detailed below:

Prerequisites

Switch on the DO meter.



- In the calibration mode, the auto stable (AS) mode is activated. Default stability setup in measurement mode is "auto stable" (AS). You can change it to "auto hold" (AH) or "real time" (RT).
- Default auto shut-off time is 30 minutes. You can set the time from ---- to 30 minutes, where ---- indicates "no auto shut-off time" has been set and meter will be on continuously.
- Default temperature unit is °C and you can change the unit to °F.
- Default reset meter setup is NO. If you like to reset the meter, you can change it to YES.

Tip _

• Stability judgment criteria remains same for both auto stability mode and auto hold mode.

- To return to the measurement mode, press the \bigwedge key.


• P3.1 Auto Stable, Auto Hold and Real Time mode setup

Auto Stable (AS) mode - the meter shows live readings () annunciator blinks until the reading is stable.

Auto Hold (AH) mode - the meter locks the stable reading;
annunciator blinks until reading is stable and then HOLD lights up.

Real Time (RT) mode - the meter shows live readings; Both ③ and HOLD annunciators are inactive.

- 1. Press the 🍣 key, **P1 D0** screen appears.
- 2. Press key, **P2 DATA** screen appears.
- 3. Press 🔺 key, P3 GEN screen appears.
- 4. Press the ENT
 key, P3.1 STBL screen appears.
- 5. Press the ENT level key, Default the stability mode is AS (auto stable).
- 6. Use the \blacktriangle vers to change the stability mode as AH (auto hold) or RT (real time).
- 7. Press the ENT key, P3.1 STBL screen appears. This indicates completion of the stability mode selection.




• P3.2 Auto shut-off time setup

- 1. Press the 🎗 key, **P1 D0** screen appears.
- 2. Press the **k**ey, **P2 DATA** screen appears.
- 3. Press the **k**ey, **P3 GEN** screen appears.
- 4. Press the ENT key, P3.1 STBL screen appears.
- 5. Press the **A** key, **P3.2 A.OFF** screen appears.
- 6. Press the ENT **•** key, default auto shut-off time is **30 minutes**.
- 7. Use the $\blacktriangle \nabla$ keys to adjust the auto off time.
- 8. Press the ENT key, P3.2 A.OFF screen appears. This indicates completion of the auto shut-off time setup.


Note

The default shut off time is 30 minutes. This can be adjusted from 1 minute to 30 minutes. If you set the display to '----' it indicates Auto Off is disabled. Meter will be on indefinitely till the user switches off the meter.




• P3.3 Temperature unit setup

- 1. Press the 🎇 key, **P1 DO** screen appears.
- 2. Press the **k**ey, **P2 DATA** screen appears.
- 3. Press the **k**ey, **P3 GEN** screen appears.
- 4. Press the ekey, P3.1 STBL screen appears.
- 5. Press the key, **P3.2 A.OFF** screen appears.
- 6. Press the **k**ey, **P3.3°C°F** screen appears.
- 7. Press the ENT key, default temperature unit is °C.
- 8. Use the $\blacktriangle \nabla$ keys to change the unit to °F.
- 9. Press the ENT key, P3.3°C°F screen appears. This indicates completion of the end temperature unit selection.



• P3.4 Reset meter (factory default)

- 1. Press the 🍣 key, **P1 DO** screen appears.
- 2. Press the **k**ey, **P2 DATA** screen appears.
- 3. Press the **k**ey, **P3 GEN** screen appears.
- 4. Press the ENT
 key, P3.1 STBL screen appears.
- 5. Press the key, P3.2 A.OFF screen appears.
- 6. Press the **A** key, **P3.3** °C°F screen appears.
- 7. Press the key, **P3.4 r.SET** screen appears.
- 8. Press the ENT
 key, default meter re-setup is NO.
- 9. Use the $\blacktriangle \nabla$ key to set it **YES**.
- 10. Press the ENT
 key. Meter displays DONE and automatically switches off.



P4 CLK setup

Real-time clock functionality is available only for LAQUA 220 meters. Using P4 Clock setup function of the meter, you can set:

Date

• Time

To set the clock function using LAQUA DO220 handheld meter, follow the procedure detailed below:

Prerequisites

Switch on the DO meter.




- Setup date and time is necessary before using the instrument for the first time or after replacing the batteries.
- Set date and time data is captured correctly while saving data in the internal memory.

_____ Tip _____

To return to the measurement mode, press the ∞ key.


P4.1 Date setup

- 1. Press the 🧏 key, **P1 PH** screen appears.
- 2. Press the key, **P2 DATA** screen appears.
- 3. Press the **k**ey, **P3 GEN** screen appears.
- 4. Press the **k**ey, **P4 CLK** screen appears.
- 5. Press the ENT **•** key, **P4.1 DATE** screen appears.
- 6. Press the **ENT** key, default set year appears.
- 7. Use the \blacktriangle \bigtriangledown keys to adjust the year.
- 8. Press the **ENT** key, default set month appears.
- 9. Use the \blacktriangle \bigtriangledown keys to adjust the month.
- 10. Press the **ENT** key, default set day appears.
- 11. Use the \blacktriangle veys to adjust the day.
- 12. Press the ENT key, P4.1 DATE screen appears. This indicates completion of the date setup.



• P4.2 Time setup

- 1. Press the 🖏 key to switch to the setup mode, **P1 PH** screen appears.
- 2. Press the **k**ey, **P2 DATA** screen appears.
- 3. Press the key, **P3 GEN** screen appears.
- 4. Press the key, **P4 CLK** screen appears.
- 5. Press the ENT key, P4.1 DATE screen appears.
- 6. Press the key, **P4.2 TIME** screen appears.
- 7. Press the **ENT** key, default set hour appears.
- 8. Use the \blacktriangle \bigtriangledown keys to adjust the hour.
- 9. Press ENT
 key, default set minute appears.
- 10. Use the $\blacktriangle \nabla$ keys to adjust the minute.
- 11. Press ENT key, P4.2 TIME screen appears. This indicates completion of the time setup.



Maintenance and storage

This section describes maintenance of LAQUA DO200 handheld meters, DO electrodes used with the meter.

Maintenance Contract

Please contact your dealer for the product maintenance contract.

Maintenance and storage of the instrument

How to clean the instrument

- If the instrument is dirty, wipe it gently with a soft dry cloth. If it is difficult to remove the dirt, wipe it gently with a cloth moistened with alcohol.
- •The instrument is made of solvent resistant materials but is not resistant to all chemicals.Do not dip the instrument in strong acid or alkali solution, or wipe it with such solutions.
- Do not wipe the instrument with polishing powder or other abrasive compound.

Environmental conditions for storage

- Temperature: 0 °C to 45 °C
- · Humidity: under 80% relative humidity and free from condensation

Avoid the following conditions

- Dusty place
- Strong vibration
- Direct sunlight
- Corrosive gas environment
- Close to an air-conditioner
- Direct wind

Maintenance and storage of the DO electrode

This section describes an overview of the procedures for maintenance and storage of DO electrode to be performed as part of daily use.

• How to clean the membrane of DO electrode

The membrane of DO electrode is extremely thin. Take care, not to tear the membrane when cleaning. Clean the membrane with deionized water and wipe it with a soft cloth, take care not to damage it.

Note

When using a neutral cleaning solution to clean the DO electrode, keep the neutral cleaning solution away from the membrane in order to prevent deterioration of the membrane.

• Daily storage of the DO electrode


Follow the steps below to store the electrode correctly. **9552-20D**, **9552-50D**

- 1. Clean the DO electrode well with deionized water.
- 2. Store electrode in carry case in a dry condition.

• When the DO electrode will not be used for a long time

Follow the steps below to store the electrode correctly. **9552-20D**, **9552-50D**

- Clean the DO electrode well with tap water, then dry it with cotton gauze.
- 2. Remove the DO tip from the DO electrode.
- 3. Attach the socket on the DO tip, then store it in a cool, dark location.



Error messages and trouble shooting

• Error message

This section describes the causes of typical errors and the actions to be taken to resolve respective errors.

If ERR is displayed while you are using the instrument, check the error, its cause and action to be taken in the error list below:

Meter display	ERR description	Cause of error and How to solve the problem			
BATT LOW	Low battery	Battery power is low. Please replace with new batteries.			
OFFS ERR	Offset voltage error	Electrode is dirty. Clean the electrode.			
SLPE ERR	Slope error	Electrode sensitivity is low. Please clean and recalibrate. If the problem persists, replace the electrode with new one.			
STD ERR	Can not auto recognize standard solution	The instrument cannot identify the standard solution. Check the calibration solution and use fresh one if required.			
P ²	Calibration interval alarm error	Exceeds the calibration interval setup. Calibrate the meter.			
MEM FULL	Memory data full	The number of the data saved has exceeded the specified number of items. Print or transfer the data. Or, clear stored data.			
ERR	If user selects the enter key before stable in calibration mode	key is pressed before the calibration value has stabilized. Wait for the value to be stable and then press the key.			

• Trouble shooting

This section describes causes and actions to take for problems that customers frequently ask. The indicated value fluctuates $% \left({{\left[{{{\rm{T}}_{\rm{T}}} \right]}_{\rm{T}}} \right)$

< Problem with the electrode >

Cause	How to solve problem		
The electrode is dirty.	Clean the electrode.		
The electrode is broken.	Replace the electrode.		

< Problem with the instrument >

Cause	How to solve problem		
There is a motor or other device causing electrical interference.	Measure at a place where no influence from induction is given. Ground all AC-powered equipment.		
The electrode is not connected correctly.	Connect the electrode properly.		

The response is slow

Cause	How to solve problem		
The electrode is dirty.	Clean the electrode.		
The electrode is broken.	Replace the electrode.		

The indicated value does not change

Cause	How to solve problem			
The electrode is broken.	Replace the electrode.			
The electrode is not connected correctly.	Connect the electrode correctly.			
Keys are locked.	Turn OFF the power, remove the batteries, and then turn ON the power again.			
The instrument is in HOLD state.	Cancel the HOLD state.			
Instrument defect.	Consult your dealer.			

The measured value is out of the measurement range

When the measured value is below the display range, "Ur" appears. When the measured value is over the display range, "Or" appears.

Cause	How to solve problem
The electrode cable is broken.	Replace the electrode.
Calibration is not performed or performed incorrectly.	Perform calibration correctly.
Instrument defect	Check as explained below.

• How to check for instrument defect

Short the metal part of the outer tube to the center pin of the electrode connector of the corresponding channel of the instrument. If "Ur" or "Or" appears in this condition, consult your dealer.



Repeatability of the measured value is poor

Cause	How to solve problem		
Effect of the sample solution.	Repeatability becomes poor when the DO of the sample changes over time.		
The electrode is dirty.	Clean the electrode.		
The internal solution of the electrode is partially depleted or contaminated.	Replace the electrode.		

Nothing appears when the power is turned ON

Cause	How to solve problem		
Power is not supplied.	Insert batteries.		
Battery polarity (+, -) is reversed.	Insert the batteries with the polarity (+, -) correctly oriented.		
Battery life is low.	Replace the batteries.		
Instrument defect	Consult your dealer.		

Swelling of keypad

Cause	How to solve problem		
Using the instrument at high elevation or other location where the air pressure is different from sea level.	To eliminate the pressure difference between the inside and outside of the instrument, briefly open and then close the serial connector cover and battery cover. After opening, correctly close the cover to maintain dust and water proofing.		
Instrument defect	Consult your dealer.		

Part of the display is missing

Cause	How to solve problem			
Instrument defect	Check the display by switching ON the instrument when all the LCD segments are lit.			

Appendix

• Appendix 1

This section describes technical information and option for LAQUA DO200 handheld meters.

• Saturated DO levels in water at various temperatures

ISO17289 (JIS K0102)

Temp. (°C)	Saturated DO (mg/L)	Temp. (°C)	Saturated DO (mg/L)	Temp. (°C)	Saturated DO (mg/L)	Temp. (°C)	Saturated DO (mg/L)
1	14.22	11	11.03	21	8.92	31	7.43
2	13.83	12	10.78	22	8.74	32	7.31
3	13.46	13	10.54	23	8.58	33	7.18
4	13.11	14	10.31	24	8.42	34	7.07
5	12.77	15	10.08	25	8.26	35	6.95
6	12.45	16	9.87	26	8.11	36	6.84
7	12.14	17	9.67	27	7.97	37	6.73
8	11.84	18	9.47	28	7.83	38	6.62
9	11.56	19	9.28	29	7.69	39	6.52
10	11.29	20	9.09	30	7.56	40	6.41

• Appendix 2

Printer format - Measurement

DO - mg/L

BA DO220	
6789	
g 2018	
28	
: DO	
ng/L	
C (MAN)	
ent	

Do - %

Meter Model	: HORIBA DO220
Serial Number	: 123456789
SW Revision	: 1.00
Date	: 20 Aug 2018
Time	: 10:10:28
Mode	: Do
Do	: 100.0 %
Temperature	: 25.0 C (MAN)
Electrode Status	: Excellent
User Name	:
Signature	:

Printer format - Data log

Meter Model	: HORIBA DO220
Serial Number	: 123456789
SW Revision	: 1.00
User Name	:
Signature	:
Logged Data	
Location	: 2
Date	: 10 Aug 2018
Time	: 10:10:28
Mode	: pH
pН	: 7.00 pH
mV	: 0.0 mV
Temperature	: 25.0 C (MAN)
Electrode Status	: Excellent
Location	: 1
Date	: 10 Aug 2018
Time	: 10:09:28
Mode	: mV
mV	: 178.0 mV
Temperature	: 25.0 C (MAN)

Printer format - Calibration

DO (%)

Meter Model	: HORIBA DO220
Serial Number	: 123456789
SW Revision	: 1.00
Date	: 20 Aug 2018
Time	: 10:10:28
Cal Points	: 100.0 %, 0.0 %
Span. Coef	: 1.23
Zero. Coef	: 0.12
Cal Temp.	: 25.0 C (ATC)
Electrode Status	: Excellent
User Name	:
Signature	:

DO (mg/L)

Meter Model	: HORIBA DO220	
Serial Number	: 123456789	
SW Revision	: 1.00	
Date	: 20 Aug 2018	
Time	: 10:10:28	
Cal Points	: 8.26 mg/L, 0.0 mg/L	
Span. Coef	: 1.23	
Zero. Coef	: 0.12	
Cal Temp.	: 25.0 C (ATC)	
Electrode Status	: Excellent	
User Name	:	
Signature	:	

• Appendix 3

Model	DO210	DO220	
Model	DO/Temp (°C/°F)		
Dissolved Oxygen (DO) Range	0.0 to 20.00 mg/L 0.0 to 200.0%		
Resolution	0.01 mg/L, 0.1%		
Accuracy	±0.1 mg/L		
Salinity Compensation	0.0 to 40.0 ppt		
Barometric Pressure Compensation	Yes		
DO Probe Type	Galvanic integrated with temperature sensor		
Calibration Points	Up to 2		
Temperature Range	-30.0 to 130.0 °C / -22.0 to 266.0 °F		
Resolution	0.1 °C / °F		
Accuracy	± 0.5 °C / ± 0.9 °F		
Calibration Option	Yes		
Memory	500	1000	
Auto Data Log	•	•	
Real-time Clock	-	•	
Date & Time Stamp	-	•	
Auto Hold / Auto Stable / Real Time	•	•	
Auto Shut-Off (1 to 30 mins.)	•	•	
Electrode Status	•	•	
Diagnostic Messages	•	•	
Software Upgrade1	•	•	
PC Communication1	-	•	
Printer Communication2	-	•	
Meter Inputs	BNC, phono		
Display	Custom LCD with backlight		
Housing	IP67, shock & resistant, non-slip		
Power Requirement	2 × AA batteries		
Battery Life	> 500 hours		
Dimensions	160 (L) × 80 (W) × 40.60 (H) mm		
Weight	Approx. 260 g (with batteries) / 216 g (without batteries)		

HORIBA Advanced Techno

31, Miyanonishi-cho, Kisshoin Minami-ku, Kyoto 601-8306, Japan http://www.horiba-adt.jp

For any questions regarding this product, please contact your local agency, or inquire from the following website. http://global.horiba.com/contact_e/index.htm

